

### 5.2.6 Using the memory

The ultimail has 6 short code memories. You can call the saved settings for postage value and endorsement in the home menu.

<input type="radio"/>	SCALES	\$ 0.00	<input type="radio"/>
<input type="radio"/>	ACCOUNT 1 MASTER	W/OUT TYPE OF MAIL	<input type="radio"/>
<input type="radio"/>	WITHOUT SMS-TEXT	WITHOUT LOGO	<input type="radio"/>
<input checked="" type="radio"/>	MEMORY	05/17/07	<input type="radio"/>
MODE: METERING Machine ready.			

- In the home menu, press the key next to MEMORY.

The SELECTING THE MEMORY menu offers the selection of all occupied short code memories. You will see the saved settings for postage value and type of mail endorsement.

SELECTING THE MEMORY			
<input type="radio"/>	1	\$ 0.41 W/OUT TYPE OF MAIL	<input type="radio"/>
<input type="radio"/>	2	\$ 0.41 -	<input type="radio"/>
<input type="radio"/>	3	\$ 4.60 PRIORITY	<input type="radio"/>
<input type="radio"/>	4	\$ 1.65 W/OUT TYPE OF MAIL	<input type="radio"/>
<input type="radio"/>	5	\$ 3.06 W/OUT TYPE OF MAIL	<input checked="" type="radio"/>
<input type="radio"/>	6	\$ 2.13 MEDIA MAIL	<input type="radio"/>
Please select a memory. To save a memory --> SETUP			

- Press the key next to the desired memory.

The ultimail goes back to home menu and displays the number of the selected memory.

The postage value and the type of mail endorsement saved are set.

If no type of mail endorsement is saved in the memory, the last selected type of mail endorsement remains set in the home menu.

Memory no. 5:  
 - Postage value \$ 3.06  
 - Metering without type of mail endorsement

No type of mail endorsement saved



For saving, changing or deleting of memories, read Chapter 11 on page 77.



You can also directly set the short code in the home menu.

- Type the memory number in the home menu.
- Confirm with the key next to MEMORY.